

Register your product at
www.philips.com/welcome.

ACT101M/19
 ACT101M/17
 ACT101M/97



Quick Start Guide

- A** Setup
- B** Enjoy
- C** Review

PHILIPS



© 2010 Koninklijke Philips Electronics N.V.
 All rights reserved. Reproduction in whole or
 in part is prohibited without the written
 consent of the copyright owner.
 Trademarks are the property of Koninklijke
 Philips Electronics N.V. or their respective
 owners.



ACT101M/17_19_97_EN
 _WK1011.5

What's in the box



Activa




Pouch



Quick Start
 Guide



Headphones,
 Ear buds, Cable clip




Arm/thigh
 band




Packing box (also a
 drinking bottle)



USB cable




- Mount the arm/thigh band, if necessary.




- Connect the headphones. Adjust the cord for close fit.

A₁ Setup


Turn on/ off Activa



- Press and hold  until the device is turned on or off.

Install software

On your PC, install the supplied software **Philips Songbird** and add-ons. **Philips Songbird** helps you collect and manage workout data and music.




A₂

- 1 Connect Activa to the PC.
- 2 On the PC, find Activa under **[My Computer]** or **[Computer]**.
- 3 Double click setup.exe to start installation.
- 4 Follow the screen instructions.

Set up your Activa


By setting up your Activa, you can select a preferred trainer; and load music for TempoMusic to match music with your pace automatically.

- 1 On the PC, launch **Philips Songbird** by double clicking the icon on the PC desktop.
- 2 Connect Activa to the PC.
- 3 On **Philips Songbird**, set up your Activa as prompted (e.g. follow ①, ②, ③, ④, ⑤):




A₃

- ① Select your current level of activity;
- ② Fill in your personal information;
- ③ select your preferred trainer;
- ④ Set a long-term goal;
- ⑤ Choose whether to fill Activa with music (up to 3 hours) from the PC.




A₄



- 4 Remove Activa from the PC safely after the transfer is complete.
→ Now, you are ready for workout.

B₁ Enjoy

Record the workout



- 1 On Activa, go to .
- 2 Select the desired sports.
- 3 Set a goal for this exercise:
To skip the step of goal setting, select **[Open ended]**.
• Select **[Calories]** or **[Time]**;
• Press or , or press and hold to select a value;
• Press to confirm.

B₂


- 4 Select **[TempoMusic]** to listen to music that matches your pace automatically.
- 5 To start recording:
 - Wear Activa properly in the position as displayed on the screen;
 - Press to start warm-up;
 - Press again to start workout.

During workout



B₃

- Press repeatedly to display the calories burnt, time used, and distance covered;
- Press repeatedly to skip songs if you listen to music (or, to switch to the next preset radio station if you listen to radio);
- Press and hold to switch between music and radio.
- Press to pause/resume/stop workout recording.



Press **BOOST** to listen to a voice report on the workout progress.

Press and hold **BOOST** to start the boost song that you filled in Activa.

C Review

You can review the workout result on Activa or on a PC for more details.

On Activa

- Go to > **[Review]**.

On a PC

- 1 Launch **Philips Songbird** on the PC.
- 2 Connect Activa to the PC
→ The workout data on Activa is automatically transferred to the PC.
- 3 On **Philips Songbird**, click **[Workouts]**.

For more information on Activa features and tips, check the User Manual. Launch Philips Songbird on the PC, and read under Help->User Manuals.

